

Claroty : Secure Remote Access to OT Systems

17-05-2023 – Claroty v3.5.2 - External Supplier Guideline

FORVIA
▪ faurecia



Content

- 01** Introduction to Claroty
- 02** Requirements to check before getting access to Claroty platform
- 03** Getting Access to Claroty Platform (basics)
- 04** Getting Access to Claroty Platform (WEB UI)
- 05** Getting Access to Claroty Platform (Claroty Application Tunnel Client)

Introduction to Claroty

- › Claroty SRA provides **Secure Remote Access to Industrial Control Systems** for maintenance, control and diagnostic
- › **Scope**
 - This user guideline provides guidance to **External suppliers providing remote support to Forvia industrial plants**

Requirements to check before getting access to Claroty platform

› Two ways of accessing the platform depending on the service required

Service	Type of connection/protocols	Access	Requirements
Server connection	<ul style="list-style-type: none"> WEB HTTP(S) VNC (only allowed for HMI) RDP SSH 	<ul style="list-style-type: none"> WEB UI URL: https://sraotz.www.forvia.com z: region (z=1 EMEA, z=3 NAO, z=5 SAO, z=7 APAC) 	<ul style="list-style-type: none"> Latest Google Chrome browser Latest Microsoft Edge browser
Application tunnel connection	<ul style="list-style-type: none"> Industrial protocols mainly 	<ul style="list-style-type: none"> Claroty client software 	<ul style="list-style-type: none"> Claroty client must be first downloaded from the WEB UI first (See slide 10) OS Supported <ul style="list-style-type: none"> ✓ Microsoft Windows OS 32-bit: Windows 10, Windows 7, Windows XP ✓ Microsoft Windows OS 64-bit: Windows 10, Windows 8, Windows 7, Windows Server 2019 / 2016 / 2012 / 2008 / 2003 Executing Claroty client requires administrator privileges






Getting Access to Claroty platform (basics)

- › New external suppliers will receive via email the **credentials** of a **Netskope account**
- › The external supplier needs to **connect first to Netskope VPN** to get access to Claroty platform
- › Once the external supplier receives the Netskope account and credentials, the **first login to the platform needs to be done via WEB UI (see slide 6)**
- › **SAML Authentication is required** for all users
- › The **same Netskope account credentials must be used** for accessing Claroty platform
- › **Access to Claroty platform**
 - URL EMEA: <https://sraot1.www.forvia.com>
 - URL NAO: <https://sraot3.www.forvia.com>

Getting Access to Claroty platform (WEB UI)

Access to Claroty platform via WEB UI

- 1- Type the WEB UI URL in the browser
- 2- Login with SAML (PingID should have been already installed in your mobile phone to provide a second factor authentication when connecting first via Netskope)
- 3- Authenticate by entering the one-time passcode
- 4- Platform is prepared to be used according to external suppliers rights. Dashboard shows available server connections




Getting Access to Claroty platform (WEB UI)

› Connecting to a server

1- Select the target **Server** and click on “**Request access**” in the dashboard view




2- In the **Request access** window, define an **expected Duration** in case of immediate access, provide a **Reason** (mandatory). As an alternative to an immediate access, **schedule a session** by checking the corresponding box and provide date and time. Click on “**Request**”




Getting Access to Claroty platform (WEB UI)

> Connecting to a server

3- Connection status turns to **Pending** while is waiting for approval by Claroty **Plant Approver**




4- Once **Approved**, click on **“Connect”** to access to the target server (immediately for the requested duration or only during the scheduled session)



Getting Access to Claroty platform (WEB UI)

> Connecting to a server

5- WEB (https)
remote view




6- Once the
session done,
click on

Disconnect

Getting Access to Claroty platform (Claroty Application Tunnel Client)



> Access to Claroty platform via Claroty App Tunnel client


- 1 First time, connect to the WEB UI to download Claroty **Client** from “**Application Tunnel**” section
- 2 Install the Client



Getting Access to Claroty platform (Claroty Application Tunnel Client)

> Access to Claroty platform via Claroty App Tunnel client

- ③ Launch the App Tunnel client 
- ④ Click on **Edit** to select the Machine Tunnel Connection. In case of a new Tunnel Connection, Add it by selecting the corresponding .sra file automatically received by e-mail each time a new Tunnel connection is created. The file can be requested to the Plant Business Key User or the user's Forvia main contact
- ⑤ Select Authenticate with **SAML**
- ⑥ Click on connection button 
- ⑦ Authenticate with **PingID**
- ⑧ Connection established. Target system is now reachable by using OT softwares





GROUP
INFORMATION
SYSTEMS